

## CASTING TOLERANCE (FROM JB/QZ4000.5—86)

Roughcast		TOLERANCE(mm)														
>	≤	CT1	CT2	CT3	CT4	CT5	CT6	CT7	CT8	CT9	CT10	CT11	CT12	CT13	CT14	CT15
	10			0.18	0.20	0.36	0.52	0.74	1.0	1.5	2.0	2.8	4.2	-----	-----	-----
10	16			0.20	0.28	0.38	0.54	0.78	1.1	1.6	2.2	3.0	4.40	-----	-----	-----
16	25			0.22	0.30	0.42	0.58	0.82	1.2	1.7	2.4	3.2	4.6	6	8	10
25	40			0.24	0.32	0.46	0.64	0.90	1.3	1.8	2.6	3.6	5.0	7	9	11
40	63			0.26	0.36	0.50	0.70	1.0	1.4	2.0	2.8	4.0	5.6	8	10	12
63	100			0.28	0.40	0.56	0.78	1.1	1.6	2.2	3.2	4.4	6	9	11	14
100	160			0.30	0.44	0.62	0.88	1.2	1.8	2.5	3.6	5.0	7	10	12	16
160	250			0.34	0.50	0.70	1.0	1.4	2.0	2.8	4.0	5.6	8	11	14	18
250	400			0.40	0.56	0.78	1.1	1.6	2.2	3.2	4.4	6.2	9	12	16	20
400	630				0.64	0.90	1.2	1.8	2.6	3.6	5.0	7	10	14	18	22
630	1000					1.0	1.4	2.0	2.8	4.0	6	8	11	16	20	25
1000	1600						1.6	3.2	3.2	4.6	7	9	13	18	23	29
1600	2500							3.6	3.8	5.4	8	10	15	21	26	33
2500	4000								4.4	6.2	9	12	17	24	30	38
4000	6300									7.0	10	14	20	28	35	44